

COVER PAGE






Thank you for purchasing the i.Tech BlueCON35 II – Wireless Audio Dongle and welcome to join our wireless exciting world of Hi-Fi quality stereo music joyfulness. Please read this user guide carefully to ensure the better enjoyment.

Table of Content

| | |
|---------------------------------------|----|
| i.Tech BlueCON35 II Overview | 4 |
| Getting Started | 4 |
| Charging your Dongle | 5 |
| Nominal Charging Time | 6 |
| Talk & Standby Time | 6 |
| Low Battery | 6 |
| Turning your Dongle on and off | 7 |
| Turning On | 7 |
| Turning Off | 7 |
| Pairing your dongle..... | 8 |
| Care and Maintenance | 9 |
| Dongle..... | 9 |
| Built-in Battery..... | 10 |
| Charging | 10 |
| Safety Information | 11 |
| Troubleshooting | 12 |
| The Dongle | 12 |
| Declaration of Conformity (DOC) | 13 |
| Product Specifications | 14 |

i.Tech BlueCON35 II Overview




Getting Started

To use your i.Tech BlueCON35 II ("the Dongle"), please follow these simple steps:

- Charge your Dongle
- Pair your Dongle with any Stereo Headset has A2DP profile

Charging your Dongle



The dongle comes with a built-in rechargeable battery. Prior to using the dongle, it is recommendable to charge the battery fully for the first time.

Charging Your Dongle

Connect the charger to an AC wall outlet and the charger plug to the dongle's charging socket (fig.2). The LED will be red while charging.

IMPORTANT Charging indication will be delayed for a few seconds if the headset has not been used for a long time or the battery is drained.

Nominal Charging Time

Charging the battery fully is normally within 3 hours. When the battery is fully charged, the LED will turn blue and remains on for 30 minutes. Disconnect the charger from AC wall outlet and the headset. Press and hold the MFB (fig.1) for 2 seconds to turn the headset on, please refer to "Turning Your Headset On and Off" on the next page.

Talk & Standby Time

The fully charged battery offers up to 6 hours talk time and up to 150 hours standby time. When no calls are in progress, the headset remains turned on in standby mode.

Low Battery

When the dongle is on and the battery becomes low, the LED flashes red. Please recharge the battery as described above.

Turning your Dongle on and off

Turning On

Press and hold the MFB for approximately 2 seconds until you see the LED flash Blue.

NOTE Press the MFB again each time you turn on the Dongle to reactivate the pairing so that the connection between the Dongle and headset is resumed. For pairing, please refer to "Pairing Your BlueCON35 II" on page 5.

Turning Off

Press and hold the MFB for approximately 3 seconds until you see the LED indicator will not flash.

Pairing your dongle

1. Press the "MFB" button and hold for 8 seconds until the LED indicator flash "Blue" and "Red" alternately
2. Press and hold your bluetooth headset (A2DP profile enabled) and start the pairing mode.
3. The dongle will start pairing automatically until the LED indicator flashes "Blue" only
4. Once the pairing has been successfully completed, the LED indicator will only flash "Blue"
5. Enjoy your stereo music with the dongle

Note :

- If LED indicator shows "Purple" or is off, please repeat step 2 - 5 again
- The default passkey of the dongle is "8888"

Care and Maintenance

Dongle

- Consider turning your Dongle off before placing it in your pocket or bag. If the MFB is accidentally depressed, your mobile handset may place an unintended call.
- Do not expose the Dongle to liquid, moisture or humidity as it is not waterproof.
- Do not use abrasive cleaning solvents to clean the Dongle.
- Do not expose the Dongle to extremely high or low temperatures.
- Do not dispose of the Dongle in a fire as it will result in explosion.
- Do not expose your Dongle to contact with sharp objects as this will cause scratches and damage.
- Do not stick anything inside the Dongle as this may damage internal components.
- Do not attempt to disassemble the Dongle as it does not contain serviceable components.
- If you do not use the Dongle for long periods, be sure to store it in a dry place, free from extreme temperatures and dust.

Built-in Battery

- Do not attempt to replace the Dongle's battery yourself as it is in-built and is not changeable.
- Charge the battery in accordance with the instruction supplied with this user guide.
- Only use the manufacturer supplied charger when charging the Dongle.

Charging

- Only use the manufacturer supplied charger when charging the Dongle.
- Do not disassemble the charger as it may expose you to dangerous voltages of other risks. Incorrect reassembly can cause electric shock when the Dongle is subsequently used.
- Do not use the charger outdoors or in damp areas.
- Only charge the Dongle's built-in battery in accordance with the instructions of this user guide.
- Avoid charging the Dongle in extremely high and low temperatures.

Safety Information

- Check local laws regarding use of a mobile handset and headset while driving. If you use the headset while driving, ensure your attention and focus remains on your responsibility of driving safely.
- Never allow children to play with the headset - small parts may be a choking hazard.
- Observe all signs that require an electrical device or RF radio product to be switched off in designated areas. These could include hospitals, blasting areas, and potentially explosive atmospheres.
- Turn off your headset prior to boarding an aircraft. Do not use your headset in an aircraft.
- Never mount or store your headset over any air bag deployment area as serious injury may result when an air bag deploys.
- Do not open or mutilate the built-in battery.
- Dispose of batteries according to local regulations. Do not dispose as household waste

Troubleshooting

The Dongle

If you are unable to connect your Dongle to the headset, please try the following:

- Ensure the Dongle is turn on and the battery is full
- Ensure the Dongle is paired with your stereo headset no more than 1 meter apart and ensure there is nothing in between
- Ensure the Stereo headset is turning on. Please refer to your stereo headset user guide for specific instruction
- Ensure the Dongle is within a maximum of 10 meters of your stereo headset and there are no obstructions, such as walls or other electronic devices in between

If the above steps do not resolve your problem, please reset your headset, remove both the batteries a while.

The i.Tech BlueCON35 II is compliant with and adopts the Bluetooth Specification 1.2. However, interoperability between the device and other Bluetooth-enabled products is not guaranteed because it depends on compatibility. For more information on the compatibility between the device with other Bluetooth-enabled products, please check with manufacturer or browse:

<http://www.itechdynamic.com>

Declaration of Conformity (DOC)

We, i.Tech Dynamic Ltd., declare that the following product:

Product Name: BlueCON35 II
Model No.: C51-A5023-XX

Is in conformity with the following essential requirements of Council Directive 1999/5/EC(referred to as R&TTE Directive): Article 3.1a, 3.1.b and 3.2. and the product is manufactured in accordance with Annex II of above directive.

A copy of the Declaration of Conformity can be found at:

<http://www.itechdynamic.com>

Product Specifications

| | |
|------------------------------|-----------------------------------|
| Bluetooth Specification: | Version 1.2 Class 2 |
| Bluetooth Profile Supported: | A2DP |
| Range of Frequency: | 2.4GHz Specturm |
| Transmitting Range: | Up to 10 meters |
| Audio Streaming Time*: | up to 9 hours |
| Dimensions: | 63 mm (L) x 23 mm (W) x 12 mm (H) |
| Cable length : | 55mm (Not include the Plug) |
| Weight : | 13.5 grams |

* May vary with difference type of batteries and user mode of operation